QUICK START

[A] Set
[B] Mode
[C] Start/Stop, Adjust
[D] Light

MODES

Press [B] to step through:
Time → Chrono → Timer → World Time → Alarm1 → Alarm2

SET TIME

In Time mode, hold [A] for 2sec
[B] to step through:
CITY → DST → SEC→ HOUR → MIN → YEAR → MONTH → DATE → 12/24
[C] / [D] to change values
[A] to exit

CHRONOGRAPH

Press [B] 1x to Chronograph
[C] start/stop
[A] reset/lap
[B] back to time

EL-BACKLIGHT

Press [D] anytime

WORLD TIME

Press [A] 2sec
[C] to step through 36 cities
DST Daylight Saving Time
[A] back to time

GMT Difference	CITY CODE	DAYLIGHT SAVINGS TIME	CITY NAME
-11	PPG	X	Samoa
-10	HNL	X	Honolulu
-9	ANC	V	Anchorage
-8	LAX	V	Los AngeL
-7	DEN	V	Denver
-6	CHI	V	Chicago
-5	NYC	V	New York
-4	CCS	X	Caracas
-3	RIO	V	Rio De Janeiro
-2	-2	X	
-1	RAI	X	Praia
0	GMT	X	Greenwich
0	LON	V	London
1	PAR	V	Paris
1	BER	V	Berlin
2	ATH	V	Athens
2	CAI	V	Cairo
2	JRS	V	Jerusalem

GMT Difference	CITY CODE	DAYLIGHT SAVINGS TIME	CITY NAME
3	JED	X	Jeddah
3	MOW	V	Moscow
3.5	THR	X	Tehran
4	DXB	X	Dubai
4.5	KBL	X	Kabul
5	KHI	X	Karachi
5.5	DEL	X	Delhi
6	DAC	X	Dacca
6.5	RGN	X	Yangon
7	BKK	X	Bangkok
8	HKG	X	Hong Kong
8	BJS	X	Beijing
9	SEL	X	Seoul
9	TYO	X	Tokyo
9.5	ADL	V	Adelaide
10	SYD	V	Sydney
11	NOU	X	Noumea
12	WLG	V	Wellington

TIMER

Press [B] 2x to Timer
Hold [A] 2sec
[B] to step through HOUR → MIN → SEC
[C] / [D] to change values
[A] to exit
[C] to start/stop
[B] back to time

SET ALARM

Press [B] 4x to Alarm1
In Alarm1 or Alarm2, hold [A] for 2sec
Press [B] to step through:
HOUR → MIN
[C] / [D] to change values
[A] to exit
[B] back to time

Press [B] 5x to Alarm2

In Alarm mode,
Press [C] to toggle alarm (left line =Alarm1, mid line=Alarm2)
Hourly chime (right line, can only be toggled from Alarm1)

CARE

Replace battery by professional.
Do not operate buttons underwater.
Clean with soft cloth and water, avoid soap.

BOCCIA®

TITANIUM

3738 LCD

Quick Start Guide

Full instruction manual: